


Notes:

Switching to the 1AC Moco is through zero voltage / potential free / dry contact closures. 'Stop' commands are issued by pulsing both 'Up' and 'Down' together momentarily (0.5 - 1.5 seconds). With this configuration, a 'Stop' command cannot be issued through the Key Switch.

The motor's active for a direction is dependent on the installation. Refer to the motor's enclosed documentation to determine the appropriate directional wire colour.

ACTIVE
NEUTRAL
EARTH

230 V 50Hz



somfy®

Project Name		© Copyright 2011 All rights reserved These drawings remain the property of Somfy and shall not be copied or used without written permission.
Date Printed 20/07/2011	Drawn By T. Wakefield	
Drawing No 0001235		