



Notes:

For BMS control of motor, two Dry Contact (0 volt) relays with a momentary latch of 0.5 - 1.5 seconds will be required.

Stop commands are issued by latching both Up and Down relays together, again momentarily (0.5 - 1.5 seconds).

LS40 Motors do not require the use of an earth cable to due to Class II classification for double insulated equipment

The Motor's Active direction is dependant on the installation. Refer to the motor's enclosed documentation to determine the appropriate directions wire colours.

ACTIVE  
NEUTRAL  
EARTH

230 V 50Hz

**somfy**

Project Name		© Copyright 2010 All rights reserved These drawings remain the property of Somfy and shall not be copied or used without written permission.
Date Printed 13/08/2010	Drawn By T.Ngo	
Drawing No 0001121		