


Telis 16 RTS & Telis 6 Chronis RTS


Overview



Telis 16



Telis 6 Chronis



Display (Auto mode): at 6:30pm, an automatic order will be sent to lower/extend the products in channel 1. The programmed time shown is always later than the current.



Manual mode: Channel 3 is programmed to a motor/group of motors named "Room 2"

Note: The Twilight feature enables summer and winter sun tracking.



This remote uses 2 AAA batteries- never use rechargeable batteries. If no action is made with the remote control within 2 minutes, it goes into "time out mode". When users "wake up" the remote control (with up/ stop-my/ down buttons), the last channel selected appears.