

Box End Entry Roller - Kit



The Roller-Kit is design to assist the curtain when moving up and down in the guide by creating less drag.

This can be done after you have installed your Rollershutter.

The position of the Roller-Kit is determined by space left in the headbox, when the curtain is in the fully up position.

When the curtain is fully up you can then mark the position of the Roller-Kit.

Then put the curtain fully down and drill the 2 holes required to fix the Roller-Kit, this is required each end of the headbox.