

Adjusting limits on the **OZROII DC8, DC15, DC35**



With motors on LHS or RHS

(after motor direction is set)

