Telis 6 Chronis RTS
## Editing an automatic order

1 **Wake up the remote**

Toggle the display to automatic mode by briefly pressing the selection button.

Hold

Press and hold the selection button until SET appears on the display.

2 **Select day to be edited**

Use the navigation button to select the desired day of the automatic order to edit.

Briefly press the selection button. EDIT and SET will appear on the display.

Briefly press the selection button.

Use the navigation button to select the existing automatic order to edit.

Briefly press the selection button. Automatic order time will begin flashing.

Is the automatic order for sunset?
Yes – continue to step 3
No – move to step 4

Telis 6 Chronis RTS
Editing an automatic order

3 — Edit automatic order for sunset

Note: if a sunset time hasn't been set, press and hold the selection button, then refer to modifying general parameters flowchart.

Use the navigation button until " ☾ " appears on the display.

Briefly press the selection button. Move to step 5.

4 — Set the time

Briefly press the selection button.

Use the navigation button to set the hour (24).

Briefly press the selection button.

Use the navigation button to set the minutes.

Briefly press the selection button.

Telis 6 Chronis RTS
Editing an automatic order

5 Select channels

Use the navigation button to select the channel to assign or change order.

Briefly press the selection button to select/deselect channels.

Use the navigation button to toggle until all channels are flashing.

Briefly press the selection button.

6 Select the order

Use the navigation button to toggle until the desired order is flashing.

Briefly press the selection button.

7 Save settings

Hold

Press and hold the selection button.

Telis 6 Chronis RTS
Editing an automatic order

START

Toggle the display to automatic mode by briefly pressing the selection button

Press & hold the selection button until "SET" appears on the display

Select the desired day of the automatic order by using the navigation buttons

Briefly press the selection button

"EDIT" & "SET" will appear on the display

Briefly press the selection button

Use the navigation button to select the existing automatic order to edit

Briefly press the selection button

Automatic order time will begin flashing

Is the automatic order for sunset?

NO

Briefly press the selection button

Use the navigation button to set the hour (24h)

Briefly press the selection button

Use the navigation button to set the minutes

Briefly press the selection button

END

Please refer to modifying general parameters flowchart

Press & hold the selection button

NO

Has a sunset time been set?

YES ▶ (from "Is the automatic order for sunset?")

YES

Using the navigation button until "☾"appears on the display

Briefly press the selection button

Use the navigation button to select the channel to assign/delete

Briefly press the selection button to Select/deselect channels

YES

Are there any more channels to assign/delete?

NO

Using the navigation button to toggle until all channels are flashing

Briefly press the selection button

Using the navigation button toggle until the desired order ('∧' 'V' or 'my') is flashing

Briefly press the selection button

Press & hold the selection button

END