

BOTTOM LIMITS DRIFTING DOWNWARDS (on a motorised blind)

Similar to the previous page example, if a bottom limit is set too close to the floor, a slight amount of drift downwards can cause excessive ripples in the skin.

At times, with a motorised blind, if it is operated intermittently in small bursts (1000mm up and down repetitively over a period) then the bottom limit can shift slightly downwards, causing the bottom bar to contact the floor resulting in loose fabric on that side. This can be restored by simply taking the blind fully up to its top limit and then returning all the way down to the bottom limit.