

EXCESSIVE WRINKLES IN THE SKIN (on a motorised blind)

As with all restrained blinds, some waves in the fabric are normal (see page #). Slidetracks patented design counteracts this as best as possible, so the 'wrinkles' should not be excessive.

Check the hood is level and the sidetracks are vertical.



**Picture above of box and track level check – THIS IS CRITICAL.*

With a spring tensioned blind, once the bottom bar is locked, the spring should pull the skin upwards to make it slightly taut. However, a motorised blind relies on the weight of the bottom bar to pull the skin downwards and create tension.

Check if the wrinkles are there during operation, or if they are only present when the blind is fully down. If the wrinkles only appear when the blind is fully down, the bottom limit may be set slightly too low – if the bottom bar is touching the floor on one side then that takes some weight and leaves slack in the skin. We recommend the bottom limit is set approximately 3mm from the bottom.



**Picture above: Left is a display blind sitting true, Right is the same blind with a minor obstruction under the right hand side of the bottom bar.*